


NEOVOLT



412-00013-00



**INSTALLATION, OPERATION &
MAINTENANCE MANUAL OF**
BW-INV-TPH4K/5K/6K/8K/10K
BW-BAT-4.8S, BW-BAT-9.6P
V0

I **DISCLAIMER**

Copyright © Bytewatt Technology Co., Ltd. 2024. All rights reserved.

No part of this document may be reproduced or transmitted in any form or by any means without prior written consent of Bytewatt Technology Co., Ltd.

The material furnished in this document is believed to be accurate and reliable. The information and recommendations in this document do not constitute commitments or warranties in the form of assignments. The information in this document is subject to change without notice. You may refer to the NEOVOLT Cloud Platform (<https://monitor.byte-watt.com>) for the most updated version.

All company and brand products and service names are trademarks or registered trademarks of their respective holders.

I **COPYRIGHT STATEMENT**

This manual is under the copyright of Bytewatt Technology Co., Ltd. with all rights reserved. Please keep the manual properly and operate in strict accordance with all safety and operating instructions in this manual. Please do not operate the product before reading through the manual.

TABLE OF CONTENTS

01	INTRODUCTION	01
	1.1 Content and structure of this document	01
	1.2 Target group	01
	1.3 Levels of warning messages	01
	1.4 Definition of abbreviations and nouns	01
02	SAFETY	02
	2.1 Intended use	02
	2.2 Safety instructions for battery	02
	2.2.1 General safety precautions	02
	2.2.2 Response to emergency situations	02
	2.3 Important safety instructions	03
	2.4 Symbols explanation	04
03	PRODUCT INTRODUCTION AND APPLICATION SCENARIOS	06
	3.1 Nomenclature introduction	06
	3.2 System introduction	06
	3.3 Product description	06
	3.3.1 Inverter electrical interface introduction	06
	3.3.2 Inverter display interface introduction	07
	3.3.2.1 Main interface of the inverter LCD	07
	3.3.2.2 Display content of sub-menu status item	07
	3.3.2.3 Display content of sub-menu history item	09
	3.3.2.4 Display content of general setting item	10
	3.3.2.5 Overloaded state	11
	3.3.3 Battery introduction	12
	3.4 Application scenarios	13
04	STORAGE AND TRANSPORT	14
	4.1 Storage	14
	4.1.1 Inverter storage	14
	4.1.2 Battery storage	15
	4.2 Transport	15
05	MOUNTING	15
	5.1 Checking the outer packing	15
	5.2 Scope of delivery	16
	5.2.1 Scope of delivery for inverter installation	16
	5.2.2 Scope of delivery for wall bracket installation(optional)	16
	5.2.3 Scope of delivery for battery BW-BAT-9.6P installation	17
	5.2.4 Scope of delivery for battery BW-BAT-4.8S installation	18

5.3 Requirements for mounting	18
5.3.1 Basic requirements	19
5.3.2 Mounting environment requirements	19
5.3.3 Mounting structure requirements	19
5.3.4 Mounting angle and stack requirement	19
5.3.5 Mounting space requirements	20
5.4 Preparing tools and instruments	20
5.5 Mounting the product	21
5.5.1 Mounting the battery	19
5.5.1.1. Mounting the battery BW-BAT-9.6P	21
5.5.1.2. Mounting the battery BW-BAT-4.8S	21
5.5.2 Mounting the inverter	27
5.5.2 Mounting the inverter (installed on the battery)	

06 ELECTRICAL CONNECTION 27

6.1 Cable requirements for connection	27
6.2 Connecting additional grounding	28
6.3 AC connection	29
6.3.1 Requirements for the AC connection	29
6.3.2 Grid and backup connection	30
6.3.3 Electricity meter connection	31
6.3.4 Configuring the chint meter	33
6.4 PV connection	34
6.5 Electrical connection between the inverter and battery packs	35
6.5.1 Electrical connection between the inverter and battery	35
6.5.2 Electrical connection between batteries	36
6.5.3 AUX/LAN/DRM、 RRCR/Meter/RS485/BMS connection	37

07 INSTALLER ACCOUNT REGISTER AND INSTALL NEW SYSTEM 38

7.1 Register on app	38
7.1.1 Download and install app	38
7.1.2 Register as installer account	38
7.1.3 Overview of functions for installer account	39
7.1.4 Install new system	40
7.2 Register on cloud	42
7.2.1 Register as installer account	42
7.2.2 Install new system	42

08 POWERING ON AND OFF THE SYSTEM 43

8.1 Powering on the system	43
8.2 Powering off the system	43

09 COMMISSIONING 44

9.1 Checking before power-on	44
9.2 Mount the cover	44

9.2.1 Mount the covers of the inverter (installed on the battery)	44
9.2.1.1. Mount the top cover	44
9.2.1.2. Mount the right cover	44
9.2.1.3. Connect the grid & backup connector and mount the cable cover	45
9.2.2 Mount the inverter with wall bracket (optional)	45
9.2.2.1. Mount the inverter	45
9.2.2.2. Mount the top cover, the mount steps same as 9.2.1.1	45
9.2.2.3. Mount the right cover and cable cover	46
9.3 Mount the Wi-Fi module	46
9.4 Wi-Fi module configuration and app usage	46
9.4.1 Wi-Fi configuration instruction guide	47
9.4.2 Check the running state	48
9.4.3 Install a new system and settings	49

10 MAINTENANCE AND TROUBLESHOOTING 52

10.1 Routine maintenance	52
10.2 Troubleshooting	52
10.2.1 Inverter error troubleshooting	52
10.2.2 Battery protection troubleshooting	55
10.2.3 Battery error troubleshooting	56

11 UNINSTALLATION & RETURN 57

11.1 Removing the product	57
11.2 Packing the product	57
11.3 Disposing of the product	57

12 SPECIFICATION 57

12.1 Datasheet of inverter	57
12.2 Datasheet of battery	61

13 CONTACT US 65

1.1. Content and structure of this document

This document is valid for:

Inverter: BW-INV-TPH4K, BW-INV-TPH5K, BW-INV-TPH6K, BW-INV-TPH8K, BW-INV-TPH10K

Battery: BW-BAT-4.8S, BW-BAT-9.6P

This document describes the mounting, installation, commissioning, configuration, operation of the product as well as the operation of the product user interface.

Read this document through, understand the safety information, and get familiar with the functions and features of the device before installing and operating it.

Illustrations in this document are reduced to the essential information and may deviate from the real product.

You will find the latest version of this document and further information on the product in PDF format at www.byte-watt.com.

1.2. Target group

This document is intended for qualified persons and end users. Only qualified persons are allowed to perform the operations marked with a warning symbol in this document. Tasks that do not require any specific qualifications will not be marked and can be performed by the end user. Qualified persons must have.

- Knowledge of working principle of inverters.
- Knowledge of how to deal with the dangers and risks associated with installing and using electrical devices, batteries and systems.
- Knowledge of the installation and commissioning of electrical devices and systems.
- Knowledge of the applicable standards and directives.
- Understood and complied with this document, including all safety precautions.
- Understood and complied with the documents of the battery manufacturer, including all safety precautions.

1.3. Levels of warning messages

The following levels of warning messages may occur when handling the product

Symbol	Description
DANGER	DANGER indicates a hazardous situation which, if not avoided, will result in death or serious injury.
WARNING	WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.
CAUTION	CAUTION indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.
NOTICE	NOTICE indicates a situation which, if not avoided, can result in property damage.
INFORMATION provides tips which are valuable for the optimal installation and operation of the product.	

1.4. Definition of abbreviations and nouns

AC	alternating current	AUX	auxiliary
APP	application	EMS	energy management system

BAT	battery	INV	inverter
BMS	battery management system	MPPT	maximum power point tracking
DC	direct current	PV	photovoltaic

02 SAFETY

2.1. Intended use

The inverter, battery packs and the electricity meters make up a system for optimization of self-consumption for a household. The inverter can achieve bidirectional transfer between AC current and DC current. The battery pack is used for the energy storage.

This system is suitable for indoor and outdoor installation.

Inverter must only be operated with PV arrays of protection class II in accordance with IEC 61730, application class A. The PV modules must be compatible with this product.

PV modules with a high capacity to ground must only be used if their coupling capacity does not exceed 1.0 μ F.

All components must operate in a scenario suitable for their operation.

Be sure to use this product in accordance with the information provided in the accompanying documents and local applicable standards and directives. Any other operation may cause personal injury or property damage.

Alterations to the product, e.g. changes or modifications, are only permitted with the express written permission of Bytewatt. Unauthorized alterations will void guarantee and warranty claims. Bytewatt shall not be held liable for any damage caused by such changes.

Any use of the product other than that described in the Intended Use section does not qualify as appropriate.

The enclosed documentation is an integral part of this product. Keep the documentation in a convenient place for future reference and comply with all instructions contained therein.

The type label must remain permanently attached to the product.

2.2. Safety instructions for battery

2.2.1. General safety precautions

- Over voltage or wrong wiring can damage the battery pack and cause deflagration, which can be extremely dangerous.
- All types of breakdown of the battery may lead to a leakage of electrolyte or flammable gas.
- Battery pack is not user-serviceable. There is high voltage in the device.
- Read the label with Warning Symbols and Precautions, which is on the right side of the battery pack.
- Do not connect any AC conductors or PV conductors directly to the battery pack which should be only connected to the inverter.
- Do not charge or discharge damaged battery.
- Do not damage the battery pack in such ways as dropping, deforming, impacting, cutting or penetrating with a sharp object. It may cause a leakage of electrolyte or fire.
- Do not expose battery to open flame.

2.2.2. Response to emergency situations

The battery pack is composed of multiple batteries and designed to prevent the danger caused by malfunction.

If the user touches the inner material of the battery cells due to damage to the shell, the following actions are recommended.

1. Inhalation: Leave the contaminated area immediately and seek medical attention.
2. Eye injuries: Rinse eyes with running water for 15 minutes and seek medical attention.
3. Skin injuries: Wash the contacted area with soap thoroughly and seek medical attention.
4. Ingestion: Induce vomiting and seek medical attention.

If a fire breaks out in the place where the battery pack is installed, perform the following counter-measures:

- **Fire extinguishing media**

1. Respirator is not required during normal operations.
2. Use FM-200 or CO₂ extinguisher for battery fire.
3. Use an ABC fire extinguisher, if the fire is not from battery and not spread to it yet.

- **Firefighting instructions**

1. If fire occurs when charging batteries, if it is safe to do so, disconnect the battery pack circuit breaker to shut off the power to charge.
2. If the battery pack is not on fire yet, extinguish the fire before the battery pack catches fire.
3. If the battery pack is on fire, do not try to extinguish but evacuate people immediately.

⚠ WARNING

There may be a possible explosion when batteries are heated above 150°C. When the battery pack is burning, it leaks poisonous gases. Do not approach.

- **Effective ways to deal with accidents**

1. On land: Place damaged battery into a segregated place and call local fire department or service engineer.
2. In water: Stay out of the water and don't touch anything if any part of the battery, inverter, or wiring is submerged.
3. Do not use submerged battery again and contact the service engineer.

2.3. Important safety instructions

⚠ DANGER

Danger to life due to electric shock when live components or cables are touched.

There is high voltage in the conductive components or cables of the product. Touching live parts and cables can result in death or lethal injuries due to electric shock.

- Do not touch non-insulated parts or cables.
- Disconnect the product from voltage sources and make sure it cannot be reconnected before working on the inverter or the battery pack.
- After disconnection, wait for 5 minutes until the capacitors have discharged.
- Do not open the product.
- Wear suitable personal protective equipment for all operations on the product.

⚠ DANGER

Danger to life due to danger voltages on the battery pack.

There is danger voltage at the pin connector for the power cable. Reaching into the pin connector for the power cable can result in lethal electric shock.

- Do not open the battery pack.
- Do not wipe over the battery pack with a damp cloth.
- Leave the protective caps on the pin connectors for the batteries power connection until the inverter cables are connected to the battery pack.
- Disconnect the system from voltage sources and make sure it cannot be reconnected before working on the inverter or the battery pack.

⚠ WARNING

Risk of chemical burns from electrolyte or toxic gases.

During normal operation, no electrolyte would leak from the battery pack and no toxic gases would form. Despite careful construction, if the battery pack is damaged or a fault occurs, it is possible that electrolyte may be leaked or toxic gases may form.

- Store the battery pack in a cool and dry place.
- Do not drop the battery pack or damage it with sharp objects.
- Only set the battery pack down on its back or its bottom.

- Do not open the battery pack.
- Do not install or operate the battery pack in potentially explosive atmosphere or areas of high humidity.
- If moisture has penetrated the battery pack (e.g. due to a damaged housing), do not install or operate the battery pack.
- In case of contact with electrolyte, rinse the affected areas immediately with water and consult a doctor without delay.

⚠ CAUTION

Risk of burns due to hot heatsink and housing.

The heatsink and housing can get hot during operation.

During operation, do not touch any parts other than the cover of the inverter.

NOTICE

Damage to the inverter due to electrostatic discharge.

- Touching electronic components can cause damage to or destroy the inverter through electrostatic discharge.
- Ground yourself before touching any component.

NOTICE

Damage due to cleaning agents.

- The use of cleaning agents may cause damage to the product and its components.
- Clean the product and all its components only with a cloth moistened with clear water.

⚠ DANGER

Danger to life due to electric shock when live components or PV cables are touched.

When PV panels exposed to sunlight, the PV array generates high DC voltage which presents in the DC conductors. Touching the live DC cables can result in death or lethal injuries due to electric shock.

- Disconnect the inverter from voltage sources and make sure it cannot be reconnected before working on the device.
- Do not touch non-insulated parts or cables.
- Do not disconnect the DC connectors under load.
- Wear suitable personal protective equipment for all work on the inverter.

⚠ DANGER

Danger to life due to electric shock from touching an ungrounded PV module or array frame.

- Touching ungrounded PV modules or array frames can result in death or lethal injuries due to electric shock.
- Connect and ground the frame of the PV modules, the array frame and the electrically conductive surfaces so that there is continuous conduction.
- Observe the applicable local regulations.

⚠ DANGER

Danger to life due to electric shock when touching live system components in case of a ground fault.

When a ground fault occurs, parts of the system may still be live. Touching live parts and cables can result in death or lethal injuries due to electric shock.

- Disconnect the product from voltage sources and make sure it cannot be reconnected before working on the device.
- Touch the cables of the PV array on the insulation only.
- Do not touch any parts of the substructure or frame of the PV array.
- Do not connect PV strings with ground faults to the inverter.

2.4. Symbols explanation

Symbol	Explanation
	Beware of a danger zone This symbol indicates that the product must be additionally grounded if additional grounding or equipotential bonding is required at the installation site.
	Beware of electrical voltage The product operates at high voltages.



Beware of hot surface
The product can get hot during operation.



Danger to life due to high voltages in the inverter, observe a waiting time of 5 minutes. Prior to performing any work on the inverter, dis-connect it from all voltage sources as described in this document.



WEEE designation
Do not dispose of the product together with the household waste but in accordance with the disposal regulations for electronic waste applicable at the installation site.



Observe the documentation.



CE marking
The product complies with the requirements of the applicable EU directives.



Certified safety
The product is TUV-tested and complies with the requirements of the EU Equipment and Product Safety Act.



RCM (Regulatory Compliance Mark)
The product complies with the requirements of the applicable Australian standards.



UKCA marking
The product complies with the regulations of the applicable laws of England, Wales and Scotland.



RoHS labeling
The product complies with the requirements of the applicable EU directives.



Risk of chemical burns.



Risk of explosion.



Risk of electrolyte leakage.



Refer to the instruction for operation.



Use eye protection.



Fire, naked light and smoking prohibited.



No nearing.



Do not dispose of the battery pack together with the household waste but in accordance with the locally applicable disposal regulations for batteries.



Recycling code.

UN38.3


Marking for transport of dangerous goods
The product passes the certifications of the UN38.3.

03 PRODUCT INTRODUCTION AND APPLICATION SCENARIOS

3.1. Nomenclature introduction

Name	Designation in this document
BW-INV-TPH4K	4kW Three-Phase Hybrid Inverter
BW-INV-TPH5K	5kW Three-Phase Hybrid Inverter
BW-INV-TPH6K	6kW Three-Phase Hybrid Inverter
BW-INV-TPH8K	8kW Three-Phase Hybrid Inverter
BW-INV-TPH10K	10kW Three-Phase Hybrid Inverter
BW-BAT-4.8S	Battery
BW-BAT-9.6P	

3.2. System introduction



BW-BAT-9.6P

Dimension(W×H×D): 590×1146×206mm


BW-BAT-4.8S

Dimension(W×H×D):
590×416+430*N×206mm
N: Number of batteries

Object	Name	Explain
1	BW-INV-TPH4K BW-INV-TPH5K BW-INV-TPH6K BW-INV-TPH8K BW-INV-TPH10K	Inverter
2	BW-BAT-9.6P BW-BAT-4.8S	Battery

3.3. Product description

3.3.1. Inverter electrical interface introduction




Position	Designation
1	Backup Connector
2	Grid Connector
3	Grounding Point
4	PV Switch
5	PV Connectors
6	BAT Connectors
7	Battery Circuit Breaker*
8	Communication Ports(CAN/RS485,BMS, LAN, METER, DRM**, AUX)
9	Wi-Fi Port
10	LCD Display

*All breakers of the product are switched off when shipped.

**The DRM is only for regions with AS/NZS 4777.2 safety regulations.

3.3.2. Inverter display interface introduction



Object	Name	Description	
A	SYS LED	Red: The inverter is in fault.	
		White: The inverter is in normal state.	
	BAT LED	White: The battery is in charging or discharging.	
	COM LED	White: The inverter is in communication.	
B	LCD Dispaly	Display the information of the energy storage system.	
C	Button Function		Escape from current interface or function.
			Move cursor to upside or increase value.
			Move cursor to downside or decrease value.
			Confirm the selection.

3.3.2.1 Main interface of the inverter LCD

<table border="1"> <tr> <td>Power</td><td>0W</td></tr> <tr> <td>Total</td><td>00.0kWh</td></tr> <tr> <td>Battery</td><td>%</td></tr> <tr> <td colspan="2">Normal</td></tr> </table>	Power	0W	Total	00.0kWh	Battery	%	Normal		<p>Main displays the inverter working status and information, including:</p> <ol style="list-style-type: none"> 1.Power: Current PV power. 2.Total: Total power generation. 3.Battery: Current remaining battery power (SOC). 4.Normal: Current working state of the equipment, including Standby. 				
Power	0W												
Total	00.0kWh												
Battery	%												
Normal													
<table border="1"> <tr> <td>>>></td><td>MENU</td><td><<<</td></tr> <tr> <td colspan="3">>Status</td></tr> <tr> <td colspan="3">History</td></tr> <tr> <td colspan="3">Setting</td></tr> </table>	>>>	MENU	<<<	>Status			History			Setting			<p>In the Main interface, press ENT key to enter the menu's main interface. Use the up and down key to select a sub-menu, press the ENT key to enter the selected sub-menu, press Return key to return to the previous layer.</p>
>>>	MENU	<<<											
>Status													
History													
Setting													

3.3.2.2 Display content of sub-menu status item

<table border="1"> <tr> <td>>>></td><td>Status</td><td><<<</td></tr> <tr> <td colspan="3">>Grid</td></tr> <tr> <td colspan="3">Soalr</td></tr> <tr> <td colspan="3">Battery</td></tr> </table>	>>>	Status	<<<	>Grid			Soalr			Battery			<p>Status menu contains five sub-menus: Solar, Battery, Grid, UPS and Comm. These display the relevant information about the current physical or communication interface respectively.</p>
>>>	Status	<<<											
>Grid													
Soalr													
Battery													

<pre>>>> Grid <<< >U1 230.2V I1 2.0A F1 49.99Hz</pre>	<p>Grid interface displays the real-time information on the utility grid side: voltage U1, current I1, frequency F1, PInv, PMeter AC, PMeter DC.</p>
<pre>>>> Grid <<< >U2 230.2V I2 2.0A F2 49.99Hz</pre>	<p>Grid interface displays the real-time information on the utility grid side: voltage U2, current I2, frequency F2, PInv, PMeter AC, PMeter DC.</p>
<pre>>>> Grid <<< >U3 230.2V I3 2.0A F3 49.99Hz</pre>	<p>Grid interface displays the real-time information on the utility grid side: voltage U3, current I3, frequency F3, PInv, PMeter AC, PMeter DC.</p>
<pre>>>> Solar <<< >U1 360.0V I1 1.0A P1 360W</pre>	<p>Solar interface displays the real-time information of PV side: voltage U1, current I1, power P1.</p>
<pre>>>> Solar <<< >U2 360.0V I2 1.0A P2 360W</pre>	<p>Solar interface displays the real-time information of PV side: voltage U2, current I2 and power P2.</p>
<pre>>>> Solar <<< >U3 360.0V I3 1.0A P3 360W</pre>	<p>Solar interface displays the real-time information of PV side: voltage U3, current I3 and power P3.</p>
<pre>>>> Battery <<< >U 96.0V I 10.0A P 960W</pre>	<p>Battery interface displays the real-time information of battery side: voltage U, current I, power P, residual capacity of Battery (SOC), the internal environmental temperature Temp.</p>
<pre>>>> UPS <<< >U1 230.2V I1 2.0A P1 460W</pre>	<p>UPS interface displays the real-time information in this mode: voltage U1, current I1, power P1, frequency F.</p>
<pre>>>> UPS <<< >U2 230.2V I2 2.0A P2 460W</pre>	<p>UPS interface displays the real-time information in this mode: voltage U2, current I2, power P2, frequency F.</p>
<pre>>>> UPS <<< >U3 230.2V I3 2.0A P3 460W</pre>	<p>UPS interface displays the real-time information in this mode: voltage U3, current I3, power P3, frequency F.</p>

<p>>>> Comm <<<</p> <p>>BMS Yes</p> <p>Net Yes</p> <p>MeterGrid Yes</p>	Communication interface displays the real-time communication situation of BMS, Net, MeterGrid and MeterDC.
--	--

3.3.2.3 Display content of sub-menu history item

<p>>>> History <<<</p> <p>>Grid Consump</p> <p>INV Gen.</p> <p>BAT Gen.</p>	History menu contains seven sub-menus: Grid Consumption, INV Gen., BAT Gen., PV Gen., Grid Charge., PV Charge., Error Logs.
<p>> Grid CONSUMP <</p> <p>> Total:</p> <p>0.0kWh</p>	Grid Consumption interface displays today's or total load consumption from grid.
<p>>>> INV Gen. <<<</p> <p>>Today:</p> <p>29.1kWh</p>	INV Gen. interface displays today's or total electricity quantity generated from Inverter.
<p>>>> Bat Gen. <<<</p> <p>>Today:</p> <p>13.8kWh</p>	Bat Gen. interface displays today's or total electricity quantity discharged from the battery.
<p>>>> PV Gen. <<<</p> <p>>Today:</p> <p>19.0kWh</p>	PV Gen. interface displays today's or total electricity quantity generated from the PV-panels.
<p>>>> Grid Charge <<<</p> <p>>Today:</p> <p>1.9kWh</p>	Grid Charge interface displays today's or total electricity quantity battery charging from the grid.
<p>>>> PV Charge <<<</p> <p>>Today:</p> <p>13.1kWh</p>	PV Charge interface displays today's or total electricity quantity battery charging from the PV-panels.
<p>>>> Error Logs <<<</p> <p>1: 2018-02-02 16:48 Chg SPI Fault</p>	Error Logs interface displays the 10 latest fault records of this device, including the name of the fault and time of error.
<p>>> Information <</p> <p>>SN: XXXXXXXXXXXXXX</p>	Make sure all numbers in the information menu are correct.

>> Information < >Inverter Ver.:	Check the inverter software version.
-------------------------------------	--------------------------------------

3.3.2.4 Display content of general setting item

> New Password < > 0 0 0 0	<p>Step1: Click setting and enter the password. The installation's password is a four-digits password: 1111, after four-digits password was correctly input, you can enter into the main Setting interface (administrator permissions).</p>	
>>> Setting <<< >Function Safety	>>> Function <<< >Solar Battery Grid	>>> Solar <<< >On Grid Cap. 000000W
<p>Step2: Click Function to enter function setting.</p>	<p>Step3: Click Solar to set the Solar relevant information.</p>	<p>Step4: Set on-grid capacity, storage capacity and number of PV strings (MPPT number).</p>
>>>> Battery <<<< >Bat Model BW-BAT-XXX	>>>> Battery <<<< >SOC Calibration No	>>>> Battery <<<< >Battery Ready No
<p>Step5: Click the Battery Function and check battery type.</p>	<p>Step6: Check SOC Calibration function set No.</p>	<p>Step7: Check the Battery Ready function set No. If you only use the inverter without battery, please set it Yes.</p>
>>>> Grid <<<< >FeedIN Control Power Limit Power Factor	Max. Feed in rate >User Value 50%	>> System Mode << >DC AC Hybrid
<p>Step8: Click the Grid Function to set up relevant parameters of the grid.</p>	<p>Step9: Set the Max. Feed in rate value.</p>	<p>Step10: Click Function-System Mode to set system mode: DC, AC, Hybrid.</p>
>>> Work Mode << >Force Charge Enable	>>> Work Mode << >Force Charge Enable	>>> Work Mode << > Charge Start Time 1 01:00
<p>Step11: Click the mode then set up work mode.(self-use or force time charge)</p>	<p>Step12: If you want to use force charge, sett Enable here.</p>	<p>Step13: Set the charge and discharge time.</p>

>>> Work Mode <<<
>UPS Reserve SOC
11%

>>>> Safety <<<<
> Country
> AS/NZS 4777.2-A
AS/NZS 4777.2-B
AS/NZS 4777.2-C

Step14: Set the UPS Reserve SOC, it means how much battery energy to reserve for UPS function.

Step15: Click Safety in the setting menu. Set safety standard. For example: AS/NZS 4777.2-A or AS/NZS 4777.2-B or AS/NZS 4777.2-C for Australia, VDE4105 for Germany, CEI 0-21 for Italy, G83_2 for Great Britain, NRS097_2_1 for South Africa, RD1699 for Spain, VDE0216 for 60Hz countries.

>>> CT Meter <<<
>Enable OFF
Ratio 1

>> UPS System <<
>Mute YES
Frequency: 50Hz

>> Date&Time <<
> 2018-02-02
09:46

Step16: If you use CT meter, please set CT meter enable and the relevant ratio.

Step17: If you use UPS function, please set the mute as YES in UPS System interface and the relevant Frequency.

Step18: Click System in the setting menu. Click Date &Time and set up the date and time.

>>> Ethernet <<<
IP method
> DHCP

Step19: Click Ethernet to set the IP address. DHCP mode means that setup IP address is set up automatically. If you want to set up the IP address manually, please choose manual mode.

Note:

It is needed to set the following 3 parameters for manual mode:

IP Address: IP address;

Subnet Mask: Subnet mask;

Default Gateway: Default gateway;

Automatic display one parameter: MAC Address: display MAC Address.

>>>> Language <<<<
> English
Deutsch
Italian

>>> Information <<<
>SN:
xxxxxxxxxxxxxx

Step20: Click Language to set Language Date & Time Setting Interface.

Step21: Make sure all the following number is correct. Date & Time Setting Interface.

3.3.2.5 Set the mode for the inverter to power quality response

<pre>>>>> Inverter power quality response <<<< > modes > Volt-var response mode Volt-watt response mode Fixed power factor Reactive power mode Power rate limit</pre>	<p>Step1: If you use Inverter power quality response, please click Inverter power quality response modes.</p>
<pre>>>>> Volt-var response mode <<<< > Values Vv1 Vv2 Vv3 Vv4 Voltage: 207V 220V 240V 258V Q% : 44 0 0 -60 Default setting:Enable</pre>	<p>Step2: Click Volt-var response mode to set the Volt-var response parameter.</p>
<pre>>>>> Volt-watt response mode <<<< > Values Vw1-ch Vw2-ch Vw1 Vw2 Voltage: 207V 215V 253V 260V P% : 20 100 100 20 Default setting:Enable</pre>	<p>Step3: Click Volt-watt response mode to set the Values parameter.</p>
<pre>>>>> Fixed power factor <<<< > PF 1.00 Default setting:Disable</pre>	<p>Step4: Click Fixed power factor to set the PF parameter.</p>
<pre>>>>> Reactive power mode <<<< > Q 0 var Default setting:Disable</pre>	<p>Step5: Click Reactive power mode to set the reactive power parameter.</p>
<pre>>>>> Power rate limit <<<< > Wgra 100 % Default setting:Enable</pre>	<p>Step6: Click Power rate limit to set the power rate parameter.</p>

>>>> Grid Protection settings <<<<

>Protective function

> Under and over voltage protection
Under and over frequency protection

Step1: If you use Grid Protection, please click Grid Protection settings.

>>>> Under and over voltage protection <<<<

>Values

	Voltage	Time
Under voltage 2 (V<<)	70V	2.00s
Under voltage 1 (V<)	180V	11.00s
Over voltage 1 (V>)	265V	2.00s
Over voltage 2 (V>>)	275V	0.20s

Step2: Click Under and over voltage protection to set the parameter.

>>>> Under and over frequency protection <<<<


>Values

	Frequency	Time
Under frequency 1(F<)	47 Hz	2.00s
Over frequency1(F>)	52 Hz	0.20s


Step3: Click Under and over frequency protection to set the frequency parameter.

3.3.2.6 Overloaded state

Power	0W
Total	00.0kWh
Battery	%
Backup Overload	




Power	0W
Total	00.0kWh
Battery	%
Please turn off some electrical..	




When overloaded, the display show "over load" and scrolls to prompt the customer to reduce some electrical appliances like this "Please turn off some electrical appliances and press the exit button to resume".

3.3.3. Battery introduction

Battery pack appearance and dimensions of BW-BAT-9.6P/BW-BAT-4.8S




Connection area overview of BW-BAT-9.6P



Position	Designation
1	Battery Positive Power Connector
2	Battery Negative Power Connector
3	Grounding
4	BMS COM 1
5	BMS COM 2 (with terminal resistance)
6	Battery LED Display
7	Battery Power Button
8	Battery Breaker

Connection area overview of BW-BAT-4.8S



Position	Designation
1	BMS COM 1
2	Battery Positive Power Connector
3	Grounding
4	Battery Circuit Breaker
5	BMS COM 2 (with terminal resistance)
6	Battery Negative Power Connector
7	Battery LED Display

The three LED indicators on the front cover provide information about the SOC operational status of this battery with lights displaying solid white or flashing.

⊕ : White LEDs flash



⊕ : White LEDs on

○ : White LEDs off

LED Indicator	No.	SOC	Description
LEDs show the SOC status	1	⊕ ○ ○	SOC≤10%
	2	⊕ ○ ○	10%<SOC≤30%
	3	⊕ ⊕ ○	30%<SOC≤50%
	4	⊕ ⊕ ○	50%<SOC≤60%
	5	⊕ ⊕ ⊕	60%<SOC≤90%
	6	⊕ ⊕ ⊕	90%<SOC≤100%


3.4. Application scenarios

Storage System (includes inverter BW-INV-TPH4K/BW-INV-TPH5K/BW-INV-TPH6K/BW-INV-TPH8K/BW-INV-TPH10K and battery BW-BAT-9.6P/BW-BAT-4.8S) can be applied in DC-coupled systems (mostly new installation), AC-coupled systems (mostly retrofit), Hybrid-coupled systems (mostly retrofit, and increase the PV capacity), and Off-grid (with Generator) systems as the following schemes show:



Hybrid-coupled Storage System

— Indicates a power cable
- - - - - Indicates a signal cable




*RCD Optional if local installation regulation required RCD installed.
**Breaker: if breaker required in applied standard.

Hybrid-coupled Storage System – Scheme

Off grid Storage System

— Indicates a power cable
- - - - - Indicates a signal cable




*RCD Optional if local installation regulation required RCD installed.
**Breaker: if breaker required in applied standard.

Off-grid (with Generator) Storage System – Scheme

Off grid Storage System with Dual power switch box

— Indicates a power cable
- - - - - Indicates a signal cable



*RCD Optional if local installation regulation required RCD installed.
**Breaker: if breaker required in applied standard.

Off grid (with Dual power switch box)Storage System – Scheme

04 STORAGE AND TRANSPORT

4.1. Storage

4.1.1. Inverter storage

The following requirements should be met if the inverter is not put into use directly:

1. Do not unpack the inverter.
2. Keep the storage temperature at -40~60°C and the humidity at 5%~95% RH.

3. The inverter should be stored in a clean and dry place and be protected from dust and water vapor corrosion.
4. A maximum of six inverters can be stacked. To avoid personal injury or device damage, stack inverters with caution to prevent them from falling over.
5. During the storage period, check the inverter periodically. Replace the packing materials which are damaged by insects or rodents in a timely manner.
6. If the inverters have been stored for more than two years, it must be checked and tested by professionals before being put into use.

4.1.2. Battery storage

The following requirements should be met if the battery is not put into use directly:

1. Place batteries according to the signs on the packing case during storage. Do not put batteries upside down or sidelong.
2. Stack battery packing cases by complying with the stacking requirements on the external package.
3. Store the battery pack out of reach of children and animals.
4. Store the battery pack where it should be minimal dust and dirt in the area.
5. Handle batteries with caution to avoid damage.
6. The storage environment requirements are as follows:
 - a. Ambient temperature: -10~55°C, recommended storage temperature: 15~30°C.
 - b. Relative humidity: 15%~ 85%.
 - c. Place batteries in a dry and clean place with proper ventilation.
 - d. Place batteries in a place that is away from corrosive organic solvents and gases.
 - e. Keep batteries away from direct sunlight.
 - f. Keep batteries at least 2m away from heat sources.
7. The batteries in storage must be disconnected from external devices. The indicators (if any) on the batteries should be off.
8. Batteries should be delivered based on the "first in, first out" rule.
9. The warehouse keeper should collect battery storage information every month and periodically report the battery inventory information to the planning department. The batteries that have been stored for nearly 6 months should be recharged timely.
10. If a lithium battery is stored for a long time, capacity loss may occur. After a lithium battery is stored for 12 months in the recommended storage temperature, the irreversible capacity loss rate is 3%~10%. It is recommended that batteries not be stored for a long period. If the batteries need to be stored for more than 6 months, it is recommended to recharge the batteries to 65~75% of the SOC.

4.2. Transport

During transportation, please follow these guidelines:

1. Priority to use the original packaging for transportation. If the original packaging is not available, put the product inside a suitable cardboard box and seal it properly.
2. Handle with care, choose the corresponding handling method according to the weight, and pay attention to safety.
3. During transportation, please keep the packaging away from dangerous sources and take waterproof measures.
4. Please fix the packaging during transportation to prevent falling or mechanical impact.

05 MOUNTING

















5.1. Checking the outer packing

Before unpacking the product, check the outer packing for damage, such as holes and cracks. If any damage is found, do not unpack the product and contact your dealer as soon as possible.






5.2. Scope of delivery













Check the scope of delivery for completeness and any externally visible damage. Contact your distributor if the scope of delivery is incomplete or damaged.

5.2.1. Scope of delivery for inverter installation










Inverter				
				
Inverter (X1)	TOP Cover (X1)	Right Cover (X1)	Cable Cover (X1)	Left Support Foot (X1)
				
Right Support Foot (X1)	PV+ & PV- Connectors (X3)	Grid Connector(X1)	Backup Connector(X1)	Small Spirit Level (X1)
	 6Pin AUX Terminal (x1) Terminals(x7)		 OT Terminal (x5) M5 Screws (x9)	
WiFi Module (X1)	6 Pin AUX Terminal Block (X2)	Power Cable Between Series Batteries (X1)	Screws and Terminals Set (X1)	Wrench Tool (X1)
				
Quick Installation Guide (X1)	System Wiring Diagram sheets (X1)	Commissioning Guide & Report (X1)		

5.2.2. Scope of delivery for wall bracket installation(optional)










Inverter				
				
Inverter (X1)	TOP Cover (X1)	Right Cover (X1)	Cable Cover (X1)	Horizontal Beams of Wall Bracket (X1)

				
Support Plate for Cable Cover (X1)	Wall Anchor (X1)	Support Stud for Right Cover (X1)	Grid Connector (X1)	Backup Connector (X1)
				
PV Connectors (X3)	Wrench Tool (X1)	WiFi Module (X1)	6 Pin AUX Terminal Block (X2)	Screws and Terminals Set (X1)
				
Small Spirit Level (X1)	Quick Installation Guide (X1)	System Wiring Diagram sheets (X1)	Commissioning Guide & Report (X1)	





5.2.3. Scope of delivery for battery BW-BAT-9.6P installation

Battery				
				
Battery Pack (X1)	Wall Anchor ST6*55 (X4)	Spanner (X1)	Left Cable Cover (X1)	Y Type Terminal (X2)
				
				
Quick Installation Guide (X1)				

5.2.4. Scope of delivery for battery BW-BAT-4.8S installation

Battery				
				
Battery (X1)	Left Cable Cover (X1)	Wall Bracket (X1)	Connecting Plate for Wall Brackets (X2)	Right Holder for Wall Bracket (X1)
				
Left Holder for Wall Bracket (X1)	Wall Anchor St6*55 (X6)	Grounding Cable (X1)	Small Gasket Screw M5x12* (X5)	Large Gasket Screw M5x12 (X3)
				
Flange Nut M5 (X6)	Quick Installation Guide (X1)	Y Type Terminal (X1)		

* Use for mounting right holder for wall bracket and left holder for wall bracket

Accessories for Base unit (optional)				
				
Base Unit (X1)	Bracket for Base (X1)	Bracket for Top Battery (X1)	Wall Anchor St6*55 (X4)	Small Gasket Screw M5x12(a) (X11)
				
Large Gasket Screw M5x12 (X17)	Connection Sheet for Wall Holders (X4)	Wrench SW16 (X1)		

(a): Use for mounting wall bracket for base and top battery.

5.3. Requirements for mounting

⚠ WARNING

Danger to life due to fire or explosion

Despite careful construction, electrical devices can cause fires.

- Do not mount the energy storage system in areas containing highly flammable materials or gases.
- Do not mount the energy storage system in potentially explosive atmospheres.

5.3.1. Basic requirements

- The Neovolt Inverter and Battery system is suitable for indoor and outdoor use.
- Do not install the inverter in a place where a person can easily touch it because its housing and heatsink are hot during operation.
- Do not mount the system in areas with flammable or explosive materials.
- Do not mount the inverter at a place within children's reach.
- Do not mount the system outdoors in salt areas because it will be corroded there and may cause fire. A salt area refers to the region within 500m from the coast or prone to sea breeze. The regions prone to sea breeze vary depending on weather conditions (such as typhoons and monsoons) or terrains (such as dams and hills).

5.3.2. Mounting environment requirements

- The system must be mounted in a well-ventilated environment to ensure good heat dissipation.
- When mounted under direct sunlight, the power of the system may be derated due to additional temperature rise.
- Mount the system in a sheltered place or mount an awning over the product.
- The optimal temperature range for the battery pack to operate is from 15 °C to 30 °C.
- Do not expose or place near water sources like downspouts or sprinklers.
- If the battery pack is mounted in the garage, then ensure that it is above the height of the vehicle bumper and/ or door.

5.3.3. Mounting structure requirements



- The mounting structure where the system is mounted must be fireproof.
- Do not mount the system on flammable building materials.
- Ensure that the mounting surface is solid enough to bear the weight load.
- In residential areas, do not mount the inverter on dry walls or walls made of similar materials which have a weak sound insulation performance because the noise generated by the inverter is noticeable.

5.3.4. Mounting angle and stack requirement

The system should be mounted on the wall.


The installation angle requirement is as follow:

- Do not mount the inverter at forward tilted, side tilted, horizontal, or upside down positions.



5.3.5. Mounting space requirements

- Reserve sufficient clearance around the product to ensure sufficient space for installation, maintenance and heat dissipation.
- The side clearance is a recommendation. Keep the clearance as short as you can if there is no influence to the operation and maintenance.



5.4. Preparing tools and instruments

Category	Tools and Instruments		
Installation			
	Hammer drill (with a $\Phi 10$ mm drill bit)	Torque socket wrench SW10	Multimeter (DC voltage range ≥ 1000 V DC)
	Diagonal pliers	Wire stripper	T20 screwdriver (torque range: 0-5 N.m) $L < 200$ mm
	Rubber mallet	Utility knife	Cable cutter
	Crimping tool (model: PV-CZM-22100)	Cord end terminal crimper	Disassembly and Assembly Tool of PV connector
	Vacuum cleaner	Heat shrink tubing	Heat gun


			
	Marker	Measuring tape	Bubble or digital level
Personal Protective Equipment			
	Safety gloves	Safety goggles	Anti-dust respirator
		 1.2×75mm	 SW 8
	Safety shoes	Flat-Head Screwdriver	Socket Wrench

5.5. Mounting the product

5.5.1. Mounting the battery





5.5.1.1. Mounting the battery BW-BAT-9.6P

- Take out the battery from the carton, transport it to the installation site with a handcart which bearing capacity should be greater than 200kg, tied with bandage.
- Place the battery against the wall, mount the wall panels and then mark drill positions.
- Fix the bolt wall bracket on the box with 3pcs M5*10 screws;
- Select a set of symmetrical OB holes for tracing points, and remove the product after tracing points are completed;
- Drill 2 holes on the wall with a diameter of 10mm and a depth of about 70mm.
- After cleaning the dust and other objects from the two holes, place 2 wall anchors into the holes, then attach the battery wall bracket to the wall by using the SW8 hexagon sleeve. Please use a level to ensure that the wall bracket is horizontal.



5.5.1.2. Mounting the battery BW-BAT-4.8S


(1) Wall bracket installation

1SW8
2.5Nm**2**SW8
2.5Nm**3****4**


(a) This recommended value is for the location which is the middle hole of the wall bracket for the bottom battery.


NOTICE

(b) Ensure that the wall bracket is mounted horizontally using a spirit level before securing the wall bracket.





5**6**

SW8



7

Note: Don't install the bracket upside down.

8**9****10****11**

Wall-mounted battery disassembly

⚠ CAUTION


Risk of injury due to the weight of the battery

Incorrectly lifting or dropping the battery during transportation, mounting, or disassembling may lead to injuries.


- Transport and lift the battery carefully. Take the weight of the product into account.
- Always have two or more people to mount and disassemble the product.
- Wear suitable personal protective equipment for all work on the product.

When disassembling the battery which has been mounted with wall bracket and not directly connected to the inverter, always hold the handles on both sides of the battery firmly and slide it to


the left. Once the contour of the round hole of the upper left handle is close with the left edge of the front cover, carefully lift the battery forward and off the wall bracket.













(2) Base Installation (Optional)





Ensure that the base is mounted horizontally using a spirit level before securing the base fixing bracket.



5**6****7****8****9****10****11****12**

13**14****14**


Note:
Be careful to prevent dust
before drilling the wall

15**16**



(a) This recommended value is for the location which is the middle hole of the wall bracket for the bottom battery.

For mounting multiple batteries, please follow as above steps.

If you will install extra batteries by side, please keep the distance between two batteries greater than 300mm. You can install extra batteries up to 6 batteries in a system.




BW-BAT-9.6P




BW-BAT-4.8S

5.5.3. Mounting the inverter


5.5.3.1. Mount the top cover



5.5.3.2. Mount the right cover




5.5.3.3. Connect the grid & backup connector and mount the cable cover



5.5.2. Mounting the inverter to battery

- Fit the left and right side brackets onto the top of the battery.
- Attach the inverter to the mounting bracket. Mount the supporting bracket at the bottom of the inverter(M5*12 2.0N.m).



06 ELECTRICAL CONNECTION

Precautions

DANGER	Before connecting cables, ensure that all breakers of the inverter and the battery packs and all the switches connected to inverters and the battery packs are set to OFF. Otherwise, the danger voltage of the energy storage system may result in electric shocks.
WARNING	<ul style="list-style-type: none"> The energy storage system damage caused by incorrect cable connections is not covered under any warranty. Only certified electricians are allowed to connect cables. <p>Operation personnel must wear proper PPE when connecting cables</p>
NOTICE	<p>The cable colors shown in the electrical connection diagrams provided in this chapter are for reference only.</p> <p>Select cables in accordance with local cable specifications (green-and-yellow cables are only used for PE).</p>

6.1. Cable requirements for connection

No.	Cable	Type	Conductor Cross Section Area Range	Outer Diameter	Source
1	Battery power cable	Standard PV cable in the industry (recommended type: PV1-F)	BW-BAT-9.6P:16mm ² BW-BAT-4.8S:10mm ²	N/A	Delivered with the battery
2	Battery communication cable	Standard network cable in the industry (recommended type: Cat5e, UTP, UV-resistant for outdoor use)	0.12 ~ 0.2 mm ² (AWG26 ~ AWG24)	N/A	Delivered with the battery
3	PV Power cable	Standard PV cable in the industry (recommended type: PV1-F)	4 ~ 6 mm ²	5.5 ~ 9 mm	Purchased by the installer
4 ^{※1}	Signal cable	Standard network cable in the industry (recommended type: Cat5e, FTP, UV-resistant for outdoor use)	0.12 ~ 0.2 mm ² (AWG26 ~ AWG24)	N/A	Delivered with the inverter
5 ^{※2}	Signal cable	Standard network cable in the industry (recommended type: Cat5e, FTP, UV-resistant for outdoor use)	0.12 ~ 0.2 mm ² (AWG26 ~ AWG24)	4 ~ 6 mm	Purchased by the installer
6 ^{※3}	Signal cable	Multiple-core outdoor shielded twisted pair cable	0.1 ~ 1.3 mm ²	4 ~ 6 mm	Purchased by the installer
7	AC power cable for backup	Five-core (4C+E) outdoor copper cable	4 ~ 6 mm ²	13 ~ 17.5 mm	Purchased by the installer
8	AC power cable for grid	Five-core (4C+E) outdoor copper cable	4 ~ 6 mm ²	13 ~ 17.5 mm	Purchased by the installer
9	PE cable	Single-core outdoor copper cable	6 ~ 10mm ²	N/A	Purchased by the installer

※1 For CT communication connection with inverter.

※2 For CAN/RS485, LAN, Meter, DRM communication connection with inverter.


※3 For AUX communication connection with inverter.

6.2. Connecting additional grounding


NOTICE	Electric Shock Hazard
Before doing electrical connection, please ensure the PV switch & all AC and BAT circuit breakers in the energy storage system are switched OFF and cannot be reactivated.	

External grounding points are provided at the left side of the inverter. Prepare M5 OT terminals, strip the grounding cable insulation, insert the stripped part of the grounding cable into the ring terminal lug and crimp using a crimping tool. Connect the OT terminal to grounding point using the torque 2.0 N.m with T20 screwdriver. Additional grounding connection for inverter.


Step 1: Additional grounding connection



Step 2: Inverter grounding point with battery




Grounding connection between inverter and battery.




Battery BW-BAT-9.6P

Step 3: Grounding connection for series battery



Step 4: Grounding connection for parallel battery



Battery BW-BAT-4.8S

6.3. AC connection

6.3.1. Requirements for the AC connection

NOTICE	Residual-current monitoring unit: The inverter does not require an external residual-current device when operating. If local regulations require the use of a residual-current device, or Hybrid-coupled storage system with big coupling capacity from the PV array and PV inverter, the following must be observed: The inverter is compatible with type A residual-current devices with a rated residual current of 100 mA or higher. Each inverter in the system must be connected to the utility grid via a separate residual-current device.
DANGER	You must protect each inverter with an individual grid/backup circuit breaker in order to ensure that the inverter can be disconnected safely.
NOTICE	For Australia and New Zealand installation site, the neutral cable of grid side and backup side must be connected together, otherwise backup output function will not work.

AC connection recommendation for 4kW			
Description	Max. Current	Breaker Type for 4kW	Recommend cable cross section
Grid Side	12.1A	16A	2.5~6mm ²
Backup Side	8.7A	16A	2.5~6mm ²

AC connection recommendation for 5kW			
Description	Max. Current	Breaker Type for 5kW	Recommend cable cross section
Grid Side	15.2A	25A	2.5~6mm ²
Backup Side	10.9A	16A	2.5~6mm ²

AC connection recommendation for 6kW			
Description	Max. Current	Breaker Type for 6kW	Recommend cable cross section
Grid Side	18.2A	25A	4~6mm ²
Backup Side	13.0A	25A	2.5~6mm ²

AC connection recommendation for 8kW			
Description	Max. Current	Breaker Type for 8kW	Recommend cable cross section
Grid Side	24.2A	32A	4~6mm ²
Backup Side	17.4A	25A	4~6mm ²

AC connection recommendation for 10kW			
Description	Max. Current	Breaker Type for 10kW	Recommend cable cross section
Grid Side	29A	40A	6mm ²
Backup Side	21.7A	32A	6mm ²


⚠ WARNING

Selecting a circuit breaker and copper conductor cross section

You should use APP or Cloud to do the right setting for example when selecting grid circuit breaker specification 32A or 40A and suitable copper conductor cross section, otherwise it increases the danger of the circuit breaker tripping under normal operating conditions.

6.3.2. Grid and backup connection

The steps for connecting the grid connector as follows:





The steps for backup connection are similar as grid connection.

! NOTE

Do not install the grid and backup connector on the inverter.

Disassembly the Grid/Backup Connector




6.3.3. Electricity meter connection

Item	Current	Scenarios
DTSU666-3*230V 5(80)A	65A(a)	Three phase meter (without CT)
DTSU666-3*230V 100A/40mA	100A	Three phase meter (with CT)
DTSU666-3*230V 250A/50mA	250A	Three phase meter (with CT)


(a): Current $\leq 65A$ Per phase

Loosen the swivel nuts of the cable glands on the COM connection cover of Inverter, and unscrew the 4 screws on the corners, then you will see the meter communication ports.




Lead the meter cable through the cable gland of the COM connection cover, don't tighten the swivel nuts of the cable glands.

Insert the RJ45 plugs to the meter communication port.



The other steps for meter (without CT) DTSU666-3*230V 5(80)A connection as follows:


Wiring at Three-phase feed in (DC)



*Breaker: if breaker required in applied standard.


DC-coupled Storage System

Wiring at Three-phase feed in (AC)



*Breaker: if breaker required in applied standard

Wiring at Three-phase feed in (Hybrid)




*Breaker: if breaker required in applied standard


6.3.4. Configuring the chint meter

Model	Grid Meter Address	PV Meter Address
DTSU666-3*230V 5(80)A (without CT)	1	2

When the meter is used as Grid meter, please follow the steps below to complete the address setting.



When the meter is used as PV meter, please follow the steps below to complete the address setting.



Meter Setting on Neovolt Cloud

Step 1:

When the system work mode is selected as DC, click the button under the "Grid Meter" to turn the "Meter" icon green.

When the system work mode is selected as AC or Hybrid, click the buttons under the "Grid Meter" and "PV side meter" to turn the "Meter" icon green.

Step 2:

Click "Save" and wait a few minutes to refresh the page.

When the "Meter Model" displays DTSU666 model, the setting is successful.

NOTICE

It is forbidden to tick CT to modify the CT ratio.

Meter Setting on "NEOVOLT" APP

Step 1:

When the system work mode is selected as DC, only tick "Meter" icon on the right of the "Grid Meter".


When the system work mode is selected as AC or Hybrid, both tick "Meter" icon on the right of the "Grid Meter" and "PV side meter".

Step 2:

Click "Submit" and enter the "System information" page to check the meter model. When the "Meter Model" displays DTSU666 model, the setting is successful.

NOTE

It is forbidden to tick CT to modify the CT ratio.



6.4. PV connection


Please ensure the follows before connecting PV strings to the Hybrid inverter:

- Make sure the open voltage of the PV strings will not exceed the max. DC input voltage (1100 Vdc). Violating this condition will void the warranty.


- Make sure the polarity of the PV connectors is correct.
- Make sure the PV-switch, breakers of battery, AC-BACKUP and AC-Grid are all in their off-states.
- Make sure the PV resistance to ground is higher than 200kOhms.

The inverter uses the Vacon D4 PV connectors. Please follow the picture below to assemble the PV connectors.

PV conductor cross section requirements: 4~6 mm².



Disassemble the PV Connectors




6.5. Electrical connection between the inverter and battery packs


6.5.1. Electrical connection between the inverter and battery

Communication cable connection:

- a. Take out the battery communication cable from the battery package.
- b. Lead the battery communication cable through the cable gland of the COM connection cover of inverter, don't tighten the swivel nuts of the cable glands, insert the RJ45 plugs to the BMS communication port.
- c. The battery communication ports of Battery series are on the side of the battery, unscrew the 4 screws of the communication panel and remove it.
- d. Loosen the swivel nut of the cable gland on the battery communication panel, lead the battery communication cable through the cable gland, insert the RJ45 plugs to the BMS communication port of Battery series.
- e. Tighten the 4 screws of the communication panel, then tighten swivel nut of the cable gland.



6.5.3 DRM Enable setting method as page:





The DRM function bellowing:

Item	Shorted pin	Description
DRM 0	Pin 5	Pin 6
DRM 1	Pin 1	Pin 6
DRM 2	Pin 2	Pin 6
DRM 3	Pin 3	Pin 6
DRM 4	Pin 4	Pin 6
DRM 5	Pin 1	Pin 5
DRM 6	Pin 2	Pin 5
DRM 7	Pin 3	Pin 5
DRM 8	Pin 4	Pin 5

6.5.4 The Generation and Expert limitation control:

Generation control can be activated as Generation limitation (Inverter generation) and Expert limitation (Considered the local load).

Limitation of Generation limit can be set as 0% to 100% of rated Apparent power, and Expert limitation can be set as 0% to 100% of rated power.



DANGER

Danger to life due to short-circuiting of the battery

Touching the short-circuit connection of the battery results in death or lethal injuries due to electric shock and massive energy release.

- Switch off the battery breaker which is located on the right side of the battery.
- Please connect both ends of one battery power cable completely before connecting the next power cable to avoid short-circuiting of the positive and negative battery power cables.


Power cable connection:

- a. Take out the battery power cables from the battery package.
- b. Remove the protective caps from the battery power connectors.
- c. Connect the battery power cables to the inverter and battery packs.

Please pay attention to the cable polarity, red cable is for battery positive.

NOTE

Before connecting the battery power cables, Replace the connector terminal at one end of the power cable in the attachment with the Amphenol H4P connector.




6.5.2. Electrical connection between batteries



For electrical connection between multiple battery packs, please follow steps as chapter 6.5.1. Electrical Connection between the Inverter and First Battery.

For grounding connection between batteries, please refer to Chapter 6.2. Grounding Connecting. You can install extra batteries up to 6 batteries in a system. Please install extra batteries by side.

NOTICE

Connect the cables between the batteries, route them from the rear side of the battery when two batteries mounting side by side.








Accessory of cables with the (*) are for battery expansion installation which need to be purchased additionally.

6.5.3. AUX/LAN/DRM&RRCR/Meter/RS485/BMS connection

For other communication (AUX, LAN, RRCR, DRM, Meter, RS485) connection, please follow the below steps.



1. Loosen the cable glands on the COM connection cover, and then unscrew the 4 screws on the COM connection cover.
2. Lead the communication cables through the cable glands of the COM connection cover, don't tighten the swivel nuts of the cable glands.
Insert the RJ45 plugs to the relative RJ45 sockets.
- 3) For meter wiring, refer to Chapter 6.3.5 for Meter Connection.
- 2) If DRM support is specified, the system may only be used in conjunction with a Demand Response Enabling Device (DRED). This ensures that the system implements the commands from the grid operator for active power limitation at all times. The system and the Demand Response Enabling Device (DRED) must be connected in the same network.
Only DRMO is available for Inverter.
- 3) Take out 6 pin terminal block for AUX connection. To do wiring connection, insert a screwdriver (blade width: 1.2 mm) into the relative connection position side.
For AUX position definition, please see the AUX wiring documentation.



3. Place the COM connection cover against the inverter housing and tighten the 4 screws, at last secure the swivel nut of the cable glands.

The pin definition of the communication ports:

ITEM \ No	1	2	3	4	5	6	7	8
BMS	NC	RS 485-A4	NC	CAN1-H	CAN1-L	NC	RS 485-B4	NC
RS485	12V	DEBUG-RXD-COM	GND	RS 485-B5	RS 485-A5	NC	DEBUG-TXD-COM	NC
METER	NC	NC	RS485-A7	NC	NC	RS 485-B7	NC	NC
DRM	DRED 1/5	DRED 2/6	DRED 3/7	DRED 4/8	REF GEN/0	COM LOAD/0	NC	NC
RRCR	K1	K2	K3	K4	3.3V	NC		
AUX 1	DO1_NO	DO1_COM	DO1_NC	DI-negative	DI-positive	GND		
AUX 2	DO2_NO	DO2_COM	DO2_NC	DI-negative	DI-positive	GND		

07 INSTALLER ACCOUNT REGISTER AND INSTALL NEW SYSTEM


7.1. Register on app

7.1.1. Download and install app

1. Android device users can download the "NEOVOLT" App through major Android application markets such as Google Play.
2. IOS device users can search for "NEOVOLT" in App Store and download the App.

7.1.2. Register as installer account

If you don't have an installer account, please register firstly.







If you already have an installer account, please log in directly.

7.1.3. Overview of functions for installer account



7.1.4. Install new system



Please enter your installer account and click Install New System to bind the system to your account and set the system.

Enter S/N, check code, license, create time, customer full name, contact number, address, and click the save button. If you are an Australian installer, you will need to fill in the Street (NMI), Suburb (NMI) and Postcode (NMI) fields and add a new Region field, which has six fixed options (NSW, QLD, VIC, SA, TAS, WA). If SA is selected for Region, two more fields are added which are Agent and NMI.

Fields that are not marked "optional" need to be filled in.

Click "Next" to go to the installation steps interface.

13:21 76

Install New System

1 Product Configuration


System Model
BW-INV-TPH10K

Battery Model

Including WiFi Module? If there is a WiFi module, please choose "Including WiFi Module" as "Yes", the APP will jump to the WiFi configuration page.

Installed, skip installation steps

Next



13:23 75

Install New System

Work Mode Select Work Mode "DC" "AC" or "Hybrid". Here set "AC" as example.

Energy Storage Inverter
PV Capacity(kWp) Set PV-inverter PV capacity.

PV-inverter PV
Capacity(kWp) Set PV-inverter PV capacity.

Max.Feed-in(%) Set allowable feedin ratio from 0%~100%.

Time zone Set time zone.


Meter on the
grid side CT
 Meter On grid side, if only a CT is installed, please select CT for grid side. If the grid meter is installed, please select Meter for grid side.

Meter on the PV
side CT
 Meter On PV side, if only a CT is installed, please select CT for PV side. If the PV meter is installed, please select Meter for PV side.

Generator Set generator status.

Last Step

Submit Click "Submit" after settings complete.



NOTICE

The safety standard must be set correctly

If you select a safety standard which is not valid for your country and purpose, it can cause a disturbance in the energy storage system and lead to problems with the grid operator. When selecting the safety standard, you must always observe the locally applicable standards and directives as well as the properties of the PV system (e.g. PV system size, grid-connection point).

- If you are not sure which safety standard is valid for your country or purpose, contact your grid operator for information on which safety standard is to be configured.

If there is a WiFi module, please choose "Including WiFi Module" as "Yes", the APP will jump to the WiFi configuration page, please refer to additional documentation "APP COMMISSIONING GUIDE".

7.2. Register on cloud


7.2.1. Register as installer account

You can create a new account on our web server for the normal monitoring. In addition, a part of our warranty is based on this connection to our web server. The data produced prior to registration can be synchronized to the web server.

Step1: Please use the following steps: Open the portal: monitor.byte-watt.com.


Step2: Please fill in "Username", "Password" and click "Login" if you have already registered.

If not, please register by filling in the following web form:



The form is titled "User registration". It contains the following fields:

- * User Type: Installer (dropdown)
- * License: Please enter the License (text input)
- * Username: someone@example.com (text input)
- * Zip Code: Please enter your zip code (text input)
- * Password: Please enter the password (text input)
- * Confirm Password: Please confirm the password (text input)
- Language: English (dropdown)
- * Contact Person: Please enter a contact (text input)
- * Country/Region: Please select your country (dropdown)
- Province/State: Please select your province (dropdown)
- City/Town: Please select your city (dropdown)
- * Contact Address: Please enter your address (text input)
- * Phone Number: Please enter your phone number (text input)
- Agree to the above terms [Terms and Conditions](#) and [Privacy Policy](#)
- Back (button)
- Submit (button)




In this form, all fields with a red star are compulsory, and you can select the finally users or installation procedures.

***Serial number:** EMS serial number.(please see the nameplate of the inverter)

***Username:** Must be an email address.

***Password:** 5-15 letters / numbers / characters
More details are available in the Online Monitoring Web Server Installers User Manual, which can be downloaded from Neovolt homepage.

7.2.2. Install new system



Log in to your installer account and choose Storage System Maintenance> "Install new system" to register new system at Neovolt Cloud.

Install New System

*SN

*Check Code

*License

*Create Time

Remark

Attachment

*Bind the current SN to an existing end user account? No Yes

*username

Enter the system S/N, check code, license, installation date and click the save button. The red * in front of it is required. Click the "Attachment" button to select the attachment you want to add.

8 POWERING ON AND OFF THE SYSTEM

8.1. Powering on the system

Procedure

Step1: Switch on the battery breaker which is at the lower left of the inverter.

Step2: Switch on the PV switch (if there is any) on the left side of the inverter.

Step3: Switch on the battery breakers of all batteries.

Step4: Shortly press the battery power buttons. For more than one parallel battery installed, please shortly press all power buttons within 10 seconds. For series batteries, please skip this step.

Step5: Switch on the AC breaker between the grid port of the inverter and the grid.

Step6: Switch on the AC breaker between the backup port of the inverter and the loads.

Step7: Switch on the AC breaker (if there is any) between the PV-inverter and the grid.

8.2. Powering off the system

⚠ WARNING

After the energy storage system is powered off, the remaining electricity and heat may still cause electric shocks and body burns. Therefore, put on protective gloves and operate the product 5 minutes after the power-off.

Procedure

Step1: Switch off the AC breaker between the Hybrid inverter and the load.

Step2: Switch off the PV switch (if there is any) on the left side of the inverter.

Step3: Switch off the PV switch on the side of the Hybrid inverter if there is any.

Step4: Long press the power button of each battery for 6 seconds. For series batteries, please skip this step.

Step5: Switch off the battery breakers of all batteries.

Step6: Switch off the battery breaker which is at the lower left of the inverter.

Step7: Switch off the AC breaker between the inverter and the grid.


9.1. Checking before power-on

No.	Check Item	Acceptance Criteria
1	Mounting environment	The mounting space is proper, and the mounting environment is clean and tidy, without foreign objects.
2	Battery pack and inverter mounting	The battery pack and inverter are mounted correctly, securely, and reliably.
3	Wi-Fi mounting	The Wi-Fi module is mounted correctly, securely, and reliably.
4	Cable layout	Cables are routed properly as required by the customer.
5	Cable tie	Cable ties are secured evenly and no burr exists.
6	Grounding	The ground cable is connected correctly, securely, and reliably.
7	Switch and breakers status	The PV switch (if there is any) and battery breakers and all the breakers connecting to the product are OFF.
8	Cable connections	The AC cables, PV cables (if there is any), battery power cables, and communication cables are connected correctly, securely, and reliably.
9	Unused power terminals	Unused power ports and communication ports are blocked by watertight caps.










9.2. Mount the cover

9.2.1. Mount the covers of the inverter (installed on the battery)

9.2.1.1. Mount the top cover




9.2.1.2. Mount the right cover


Step 1**Step 2****9.2.1.3. Connect the grid & backup connector and mount the cable cover****Step 1****Step 2****Step 3****9.2.2. Mount the inverter with wall bracket (optional)****9.2.2.1. Mount the inverter****Step 1****Step 2****Step 3****9.2.2.2. Mount the top cover, the mount steps same as 9.2.1.1**

9.2.2.3. Mount the right cover and cable cover

Mount the right cover




Mount the cable cover



9.3. Mount the Wi-Fi module.

Remove the Wi-Fi protection cover and screw the Wi-Fi module.



After finishing electrical connection of energy storage system, do the following operations.

- Check the voltage range and frequency range of the grid and the installation of meter (without CT).
- Install the top and right decorative cover of the inverter.
- Follow the instructions in Chapter 8.1. to powering on the system.
- Install the cable cover of the inverter.

9.4. Wi-Fi module configuration and app usage

This section is for users who have an energy storage system with a Wi-Fi module.

Neovolt APP is able to configure the network, set system basic parameter, monitor system operation status and check configuration information.

Please refer to below documentation "APP COMMISSIONING GUIDE" for more details on APP setup and usage.

9.4.1. Wi-Fi configuration instruction guide






Section1 Preparing work


Step1: Make sure the interver's Wi-Fi dongle is powered on ;

Step2: Make sure the Wi-Fi router is powered on;


Step3: Searching "NEOVOLT" to Download and install the APP from APP Store (IOS) / Installing Google Play APP, then searching "NEOVOLT" to download and install the APP from Google Play APP (Andriod).

Section2 Wi-Fi configuration


		
<p>Step1 : Open the "NEOVOLT" APP and Click "Wi-Fi Configuration"</p>	<p>Step2 : Click "I know, go to config-ure"</p>	<p>Step3 : Click "Next"</p>
		
<p>Step4 : Click "Open the Wi-Fi network list"</p>	<p>Step5 : Select the Wi-Fi SSID (named after SN) and input the default Password (12345678) , then go on</p>	<p>Step6 : Select the Wi-Fi network name of home router</p>



Step7 : Enter the home router Password, click "Submit"



Step8 : Wait until router successfully configured, click "Next"



Step9 : Set the parameters, then click "Submit"


9.4.2.Check the running state

Section1 : Check the running state without PV and battery

Step1 : Keep the switch of the Inverter's PV off; Keep the switch of Inverter's AC(Connected the Grid) off; Keep the switch of Inverter's battery off;

Step2 : Turn on the switch of Inverter's AC (Connected the Grid), Connect to the Load; Then the "SYS" of the inverter's LED will be RED (Bypass);

Step3 : Check the data of the "GRID POWER" in the "System Configuration" Page; Under normal circumstances, the data is a positive number; If the data is a negative number, please check the Grid-side CT or check if the meter is connected in the correct direction.




Section2 : Check the UPS state

Step1 : Turn on the switch of the Inverter's battery;

Step2 : Connect to the Load;

Step3 : Turn off the switch of the Inverter's AC (Connected the Grid);

Step4 : Check if the data of the "WORKING STATUS" in the "System Configuration" page is "UPS", and also check if the Load working normally.



Section3 : Check the running state of PV and battery


Step1 : Switch off the AC breaker between the grid port of the energy storage inverter and the grid, and switch off the AC breaker between the backup port of the energy storage inverter and the loads;

Step2 : Press the battery button. If there are more than one battery, press the button of each battery and the interval time of powering on each battery should be less than 5s;

Step3 : Switch on the AC breaker between the grid port of the energy storage inverter and the grid;

Step4 : Switch on the PV switch on the energy storage inverter and AC breaker on the PV-inverter if any;

Step5 : Switch off all the loads to see the battery charging status and the inverter LED ("SYS")* will be solid on white. Battery power value should be negative. If the system is in AC or hybrid mode, the PV inverter power value should be positive. If it is not normal, please check the direction of PV CT or PV meter installed.




9.4.3. Install a new system and settings

Section1 Download the App

Download and install “NEOVOLT” App.

Section2 Register as an installer




Step1 : Open the NEOVOLT App and click "Register"


Step2 : Choose your role and input the information. Click"Next"

Step3 : Input license number,contact number and other informations needed, then Click OK, Verify email


Section3 Install new system



Step1 : Click "Me", then click "Install New System"




Step2 : Get your "S/N" and Check code from the electrical parameter label, input them then click "Next"




Step3 : Input the further information step by step.(If you have some problems, pls refer to the APP Manual Guide)

Section4 Check the running state on-line


Step1: Check the Charging Function of the Product.



① Click "Me", then Click "System List"




② Choose your system (SN)



③ Click "Function", then click "Charging / Discharging setting"

NOTICE

If the operation is normal as described in "Step3", please remember to deactivate the "Charging/-Discharging Setting" by clicking "OFF" and save the changes.



④ Select "ON" to Charge Batteries from Grid, set "Charging Period 1" and the SOC should be "100" under this function



⑤ Make sure the setting is correct

If not correct, please check the CT or meter installed direction of both grid and PV side

TIPS :

The relative value should be like this :

Load = PV ± GRID-Battery; ;

Battery should be in **charging** status;

PV arrow should be as shown in the picture;

± :

>> absorbing for grid: +;

<< feed-in to grid - .

Section5 Check the PV generation and discharging function of the product



Step1 : Check the battery discharging status

- ① Switch off the PV;
- ② Switch on the inverter;
- ③ Switch on the AC breaker on the PV inverter if there is any.

TIPS :

The relative value should be like this:

Load = GRID + Battery.



Step2 : Check the system running status

- ① Switch on the PV;
- ② Switch on the inverter;
- ③ Switch on the AC breaker on the PV inverter if there is any.

TIPS :

The relative value should be like this :

Load = PV ± GRID ± Battery;

± : charging : - ; discharging : + ;

PV arrow should be as shown in the picture;

± :

>>absorbing for grid : +;

<< feed-in to grid : -. .

Step3 : Check the UPS state of the product

- ① Switch off the external AC breaker between the grid and the inverter. The inverter will enter the UPS mode at once;
- ② Switch on the external AC breaker between the inverter and the backup load;
- ③ Please connect a low-power electrical appliance to the socket of backup load;
- ④ If the electrical appliance can work normally, it means that the wiring of the backup has been connected correctly.

Notice : During commissioning, if the LED indicators on the display panel of the inverter or the battery pack show red, please refer to chapter troubleshooting.

Tips : Please don't forget to switch on all of the breakers.

10 MAINTENANCE AND TROUBLESHOOTING

10.1. Routine maintenance

Normally, the energy storage system need no maintenance or calibration.

However, in order to maintain the accuracy of the SOC, it is recommended to perform a full charge calibration for SOC (charging battery until the charging power is 0) on the battery at regular intervals (such as two weeks).

Disconnect the system from all power sources before cleaning. Clean the housing, cover and display with a soft cloth.

To ensure that the energy storage system can operate properly in the long term, you are advised to perform routine maintenance on it as described in this chapter.

Maintenance checklist

Check Item	Acceptance Criteria	Maintenance Interval
Product cleanliness	The heatsink at the back of the product are free from obstacles or dust.	Once every 6 to 12 months
Product visible damage	The product are not damaged or deformed.	Once every 6 months
Product running status	1. The product operate with no abnormal sound. 2. All parameters of the product are correctly set. Perform this check when the product is running.	Once every 6 months
Electrical connections	1. Cables are securely connected. 2. Cables are intact, and in particular, the cable jackets touching the metallic surface are not scratched. 3. Unused cable glands are blocked by rubber sealing which are secured by pressure caps.	Perform the first maintenance 6 months after the initial commissioning. From then on, perform the maintenance once every 6 to 12 months.

⚠ CAUTION

Risk of burns due to hot heatsink and housing

The heatsink and housing of the inverter can get hot during operation.

- During operation, do not touch any parts other than the cover.
- Wait approx. 30 minutes before cleaning until the heatsink has cooled down.

10.2. Troubleshooting

10.2.1. Inverter error troubleshooting

Error No.	Error description	Troubleshooting
100007	Insulation_fault	1. Check whether PV cable connection is reliable. 2. Check whether PV cable is damaged.
100008	GFCI_fault	Restart system and check whether the fault is existing.
100009	Leakage current test failure	

100025	BAT_OVP	Check whether the actual battery voltage exceeds the battery charging cut-off voltage by more than 20V.
100026	BAT_UVP	Check whether the actual battery voltage is lower than the battery discharge cut-off voltage.
100042	Output_short_circuit	<ol style="list-style-type: none"> 1. Use a multimeter to test the impedance of the off grid output. If it is small, check whether the wiring is correct. 2. Restart system, if error still exists, please call the service center.
100043	Output_overload	<ol style="list-style-type: none"> 1. Check whether the load exceeds the rated power. 2. Restart system, if error still exists, please call the service center.
100043	Grid Load Reverse	<ol style="list-style-type: none"> 1. Check whether cables are reversed (whether Grid cable is connected to the Backup side). 2. Restart system, if error still exists, please call the service center.
100144	LPE Reverse	<ol style="list-style-type: none"> 1. Check whether the L cable is connected to the Grounding. 2. Restart system, if error still exists, please call the service center.
100160	DCI	Restart system to see if the fault still exists. If still exists, please call the service center.
100161	SW Consistency	Perform the remote upgrading again and ensure that the version of CPU1 and CPU2 upgrade files is the same.
100162	N-N Reverse Lost	<ol style="list-style-type: none"> 1. The system installed in Australia needs to check whether N-N is short-circuited. 2. If not in Australia, set the safety standard correctly. 3. Restart system, if error still exists, please call the service center.
100220	inv_line_short	<ol style="list-style-type: none"> 1. Check whether the load is short-circuited connected. 2. Restart system, if error still exists, please call the service center.
110000	Bat over-voltage alarm	Check that the actual battery voltage is 10V higher than the battery charging cut off voltage.
110001	Bat under-voltage alarm	Check that the actual battery voltage is 10V higher than the battery discharging cut-off voltage.
110002	output_overload_alarm	Check whether the load exceeds 0.95 of the rated power.

110019	Bat Reverse	Check whether battery positive and negative connections are reversed.
110021	Grid Loss	
110022	Grid Volt	1. Wait for the Grid power return to normal. 2. If Grid is normal, check the connections to the grid terminal. 3. Restart system, if error still exists, please call the service center.
110023	Grid Freq	
110024	10min Grid Volt	
110026	PE Loss	1. Check whether the grounding cable is disconnected. 2. Restart system (This warning does not affect system running).
110027	LN Reverse	1. Check whether the Grid L/N cable are reversed connected. 2. Restart system, if error still exists, please call the service center.
110028	Low Temperature	1. Wait for the temperature to return to normal (above -20°C). 2. If temperature is normal, restart system, if error still exists, please call the service center.
110029	GFCI	1. Check whether there is leakage current in system cables. 2. If no abnormal connection, but still error frequently, please call the service center.
110033	Island	Normal protection mode, no action is required.
110034	Fan Abnormal	Restart system, if error still exists, please call the service center.
110035	N Loss	1. Check whether the Grid N cable is disconnected. 2. Restart system, if error still exists, please call the service center.
110039	Machine Type	Restart system, if error still exists, please call the service center.
110040	Inv Volt Low	1. Check whether the Backup load power exceeds the inverter rated power. 2. Restart system, if error still exists, please call the service center.
110047	Bus Under	1. Wait for the Grid power restore to normal. 2. Charge the battery and wait until the battery restore.

110051	Reduce PBy Over Freq	Wait for the Grid power restore to normal.
110052	Reduce PBy Over Volt	Wait for the Grid power restore to normal.
110053	Reduce PBy Over Temp	Wait for the inverter temperature returns to normal.
110054	HVRT	Wait for the Grid power restore to normal.
110055	LVRT	Wait for the Grid power restore to normal.
110056	Bat Open	Check the battery circuit breaker and the battery circuit breaker on the inverter are on.
110060	EMS CAN ALARM	Restart system, if error still exists, please call the service center.
110061	EMS SCI ALARM	Restart system, if error still exists, please call the service center.
110074	PV Over Volt	<ol style="list-style-type: none"> 1. Check whether the configured voltage of the PV panel is greater than 950V(Use a multimeter to measure the PV terminal voltage). 2. Restart system, if error still exists, please call the service center.
110082	N-N Reverse Lost	<ol style="list-style-type: none"> 1. The system installed in Australia needs to check whether N-N is short-circuited. 2. If not in Australia, set the safety standard correctly. 3. Restart system, if error still exists, please call the service center.
110083	bat_num_abnormal	Restart system, if error still exists, please call the service center.

10.2.2. Battery protection troubleshooting

LED Indicator	Error Code	Description	Troubleshooting
Yellow LEDs on or Yellow LEDs flash once per second.	1	Temperature difference	Wait for automatic recovery. If the problem is not be solved yet, please call the service center.
	3	High Temperature	Stop discharging and charging until this code is eliminated and wait for the temperature to drop.
	4	Low-temperature discharge	Stop discharging until this code is eliminated and wait for the temperature to rise.

Yellow LEDs on or Yellow LEDs flash once per second.	5	Over-current charge	Wait for automatic recovery. If the problem is not be solved yet, please call the service center.
	6	Over-current discharge	
	8	Cell overvoltage	
	9	Cell undervoltage	Stop discharging and call the service immediately.
	11	Low-temperature charge	Stop discharging until this code is eliminated and wait for the temperature to rise.

⚠ NOTE

In the case of work mode, if the protection code 9 appears, please press the power button of the battery 5 times within 10 seconds, the BMS will be forced to turn on the MOSFET of discharge so that the inverter can detect the battery open voltage and charge the battery.

10.2.3. Battery error troubleshooting

LED Indicator	Error Code	Description	Troubleshooting
Yellow LEDs on or Yellow LEDs flash once per second.	Error 01	Hardware error	Wait for automatic recovery. If the problem is not be solved yet, please call the service center.
	Error 05	Hardware error	
	Error 06	Circuit breaker open	Switch on circuit breaker after powering off the battery.
	Error 08	LMU disconnect(slave)	Reconnect the BMS communication cable.
	Error 09	SN missing	Call for service.
	Error 10	LMU Disconnect(master)	Reconnect the BMS communication cable.
	Error 11	Software version inconsistent	Call for service.
	Error 12	Multi master	Restart all batteries.
	Error 13	MOS over temperature	Power off the battery and power on the battery after 30minutes.

Yellow LEDs on or Yellow LEDs flash once per second.	Error 14	Insulation fault	Restart battery and in case the problem is not resolved, call for service.
	Error 15	Total voltage fault	Restart battery and in case the problem is not resolved, call for service.

10.2.4 Earth fault alarm and troubleshooting:

The earth fault alarm is enabled default, the earth connection abnormal will cause indicator of red light of interface of front view of inverter.

1. Check whether the grounding cable is disconnected, or bad connected.
2. Restart system (This warning does not affect system running).

11 UNINSTALLATION & RETURN

11.1. Removing the product

Procedure


- Step 1: Power off the energy storage system by following instructions in Chapter 8.2. Powering Off the System.
- Step 2: Disconnect all cables from the product, including communication cables, PV power cables, battery power cables, AC cables, and PE cables.
- Step 3: Remove the WiFi module.
- Step 4: Remove the product from the wall bracket. Remove the expansion battery from the wall bracket.
- Step 5: Remove the wall brackets.

11.2. Packing the product

If the original packaging is available, put the product inside it and then seal it using adhesive tape. If the original packaging is not available, put the product inside a suitable cardboard box and seal it properly.

11.3. Disposing of the product

- If the product service life expires, dispose of it according to the local disposal rules for electrical equipment and electronic component waste.
- Dispose of the packaging and replaced parts according to the rules at the installation site where the device is installed.
- Do not dispose the product with normal domestic waste.



12 SPECIFICATION

12.1. Datasheet of inverter

Item	BW-INV-TPH4K	BW-INV-TPH5K	BW-INV-TPH6K	BW-INV-TPH8K	BW-INV-TPH10K
Input DC (PV side)					
Recommended Max. PV power	8000W	1000W	1200W	16000W	20000W
Max. PV Input Voltage	1100 V				
Rated Voltage	720 V				

Start-up Voltage	85 Vdc				
DVC	DVC-C				
Mppt Voltage Range	140 ~ 950 V				
Max. Input Current Per MPPT	16 A / 16 A / 16 A				
Max. Short Circuit Current Per MPPT	24 A / 24 A / 24 A				
MPPT Number	3				
Max Input Strings Number Per MPPT	1				
Back feed current	0A /0A /0A				
Battery					
Battery Type	LFP (LiFePO ₄)				
Battery Voltage Range	90 ~ 700 V				
DVC	1 battery: DVC-B/2,3,4,5,6 battery in serial: DVC-C				
Maximum Charging Power	4 kW	5 kW	6 kW	8 kW	10 kW
Maximum Charge/ discharge current	50 A / 50 A				
Communication	CAN				
Back feed current	50A				
Output AC (Back-up)					
Rated Output Power	4 kW	5 kW	6 kW	8 kW	10 kW
Max Apparent Output Power	4.4 kVA	5.5 kVA	6.6 kVA	8.8 kVA	11 kVA
Back-up Switch Time	<20 ms				
Rated Output Voltage	3L/N/PE, 380/400V				
Rated Frequency	50/60 Hz				
Rated Output Current	5.8 A	7.2 A	8.7 A	11.6 A	14.5 A
THDV(@linear load)	< 3%				
DVC	DVC-C				
Back feed current	Not applicable				

Input AC (Grid side)					
Rated Input Power	8 kW	10 kW	12 kW	16 kW	20 kW
Max. Input Current	12.1 A	15.2 A	18.2 A	24.2 A	29 A
Output AC(Grid side)					
Rated output power	4 kW	5 kW	6 kW	8 kW	10 kW
Max. Apparent Output Power	4.4 kVA	5.5 kVA	6.6 kVA	8.8 kVA	11 kVA
Operation Phase	Three phase				
Rated Grid Voltage	3L/N/PE, 380/400V				
Grid Voltage Range	180 ~ 270 Vac				
Rated Grid Frequency	50 / 60 Hz				
Rating Grid Output Current	5.8 A	7.2 A	8.7 A	11.6 A	14.5 A
Power Factor	>0.99 (0.8 leading to 0.8 lagging)				
THDI	< 3%				
Protection Class	I				
Pollution Degree	II				
Overvoltage Category	III				
DVC	DVC-C				
Anti-islanding protection Method	Frequency shift				
Efficiency					
Max Efficiency	>97.8 %	>97.8 %	>97.8 %	>98 %	>98 %
EU Efficiency	>97.3%	>97.3%	>97.3%	>97.5%	>97.5%

Protection	
Anti-Islanding Protection	Integrated
Insulation Resistor Detection	Integrated
Residual Current Monitoring Unit	Integrated
Output Over Current Protection	Integrated
Output Short Protection	Integrated
Output Overvoltage Protection	Integrated
DC Reverse Polarity Protection	Integrated
PV Overvoltage Protection	Integrated
PV Switch	Integrated
Battery Breaker	Integrated
General Data	
Dimensions (W*H*D)	590*416*205 mm
Weight	29 kg
Topology	Transformerless
Operation Temperature Range	-25 ~ +60 °C
Ingress Protection	IP65
Noise Emission	<30 dB
Cooling Concept	Natural convection
Max. Operation Altitude	3000 m
Grid Connection Standard	G98, VDE-AR-N 4105, EN 50549-1, VDE 0126, RD 1699, CEI 0-21, C10/11, NRS 097-2-1, TOR Erzeuger, MEA, PEA, AS/NZS 4777.2

Safety/ EMC Standard	IEC62109-1/-2 IEC/EN61000-6-1/2/3/4
Features	
PV Connection	Vaconn D4 connectors
Grid Connection	Plug in connector
Back-up Connection	Plug in connector
BAT Connection	Amphenol H4 connectors
Communication	LAN, Wi-Fi
Warranty	5 years standard (10 years optional)

12.2. Datasheet of battery


Model	BW-BAT-9.6P	BW-BAT-4.8S
Battery Type	LFP (LiFePO4)	LFP (LiFePO4)
Weight	85.7 kg	53 kg
Dimension (W*D*H)	590 * 730 * 206 mm	590 * 430 * 206mm
Ingress Protection	IP65	IP65
Energy Capacity	9.6 kWh	4.8 kWh
Usable Capacity	9.1 kWh	4.56 kWh
DoD	95%	95%
Nominal Voltage	96 V	96 V
Operating Voltage Range	90 ~ 108 V	90 ~ 108 V
Max. Charging / Discharging Current *	50 A/50 A	50 A/50 A

Operating Temperature Range	Charge: 0<T<50 °C / Discharge: -10<T<50 °C
Monitoring Parameters	System voltage, current, cell voltage, cell temperature, PCBA temperature
BMS Communication	CAN
System	
Safety	IEC62619/IEC62040
Warranty	5 Years product warranty, 10 Years performance warranty
Transportation	UN38.3

* Max. charge/discharge current derating will occur related to temperature and SOC.


Appendix 1: System overview

Please see the following wiring diagram of the system principle, divided into European, Australian and other regions.




2. Three-Phase Inverter System Wiring Diagram with Electricity Meter DTSU666 (With CT)

NOTICE
(Only for Australia and New Zealand installation site)




1. Three-Phase Inverter System Wiring Diagram with Electricity Meter DTSU666 (Without CT)


AC	BACKUP
L1-----A	L1-----A
L2-----B	L2-----B
L3-----C	L3-----C




2.Three-Phase Inverter System Wiring Diagram with Electricity Meter DTSU666 (With CT)



1.Three-Phase Inverter System Wiring Diagram with Electricity Meter DTSU666 (Without CT)(EU)



2.Three-Phase Inverter System Wiring Diagram with Electricity Meter DTSU666 (With CT)(EU)



Appendix 2: Regional application standard

Please check with your local grid company and choose the correspond Regional Application Standard, the power quality modes Volt-var and Volt-Watt will be running automatically. (Only for regions with AS/NZS 4777.2 safety regulations).

Regional Application Standard	Electric Company
Australia A	N/A
Australia B	N/A
Australia C	N/A
New Zealand	N/A
Vector	New Zealand Vector

13 CONTACT US

Name: Bytewatt Technology Co.,Ltd.

Tel: +86 180 1268 7058

Address: No.137, West Shihu Road, Wuzhong District, Suzhou City, Jiangsu Province, P.R.China
Postcode: 215000